



ZTL ARTCC  
TRI-CITIES REGIONAL AIRPORT  
TRI-CITY ATCT  
BLOUNTVILLE, TENNESSEE

STANDARD OPERATING PROCEDURES  
EFFECTIVE: 1/19/2019

# ZTL ARTCC

## TRI CITY

---

### GENERAL

Callsign		Frequency	VOX Channel
ATIS		118.250	KTRI_ATIS
Ground Control	TRI_GND	121.900	TRI_GND
Local Control	TRI_TWR	119.500	TRI_TWR
Approach	TRI_APP	125.500	TRI_APP

### CLEARANCE DELIVERY

Type	Altitude
IFR	5000
VFR	3500

### GROUND CONTROL

Ground Control is responsible for all taxiways and movement areas.

### LOCAL CONTROL

Local Control airspace is a 4NM ring around KTRI from the Surface to and including 4,000 feet.

### MISSED APPROACH

Runway	Altitude	Heading
5/9	5000	RH
23/27	4000	RH

### HELICOPTER OPERATIONS

All Helicopters are located on the GA Ramp located just North of the tower. Advise to stay West of all RW's or Air/Hover Taxi to a position where it is feasible for them to depart for their direction of flight.

## APPROACH / DEPARTURE

The TRI TRACON is delegated that airspace from the surface up to and including 10,000'

### DEPARTURE PROCEDURE

Single IFR departure: KINGS 1 – radar vectors to first fix.

### INSTRUMENT APPROACHES

Approach	Runway	IAF	FAF
ILS	5	BOOIE	BOOIE
ILS	23	GZG/MOCCA	MOCCA
RNAV GPS	5	HOSEM	AYABU
RNAV GPS	27	KEPDE	FAVKA
RNAV GPS	9	BOYVA	CODAM
RNAV GPS	23	BUYBA	ECIDA

### CLASS E AIRFIELDS

Id	Name	Runway	Approach
KVJI	Virginia Highlands Abingdon, VA	06/24	RNAV (GPS) 06/24 LOC 24
KGCY	Greene County Greeneville, TN	05/23	RNAV (GPS) 05 NDB 05
KRVN	Hawkins Co. Rogersville, TN	07/25	RNAV (GPS) 07/25 NDB 07
0VG	Lee County Jonesville, VA	07/25	RNAV (GPS) 07/25
0A9	Elizabethton, TN	06/24	RNAV (GPS) 06
6A4	Johnson County Mountain City, TN	06/24	RNAV (GPS) 06/24

### LETTER OF AGREEMENTS

ZID	North departures from KTRI hand off to ZID Arrivals from ZID will be descended to 10,000' prior to h/o to TRI